



Radial Pull

Trouble shooting of pulling

vehicle pulling on accelerating or braking is made by vehicle drive system, so have to test on regulation speed test as below (80km/h speed, Distance 100m)



Vibration and pulling phenomenon are mainly caused as follows:

- Failure to vehicle maintenance
- Deformed rim
- Incompatibility between tire and vehicle or rim when replace tire for new one, because tire has a straight property.

Mainly, it happens by mix with above problem so need to take care of owner's car now and then.

Also, tire engineer must check vehicle and rim condition before mounting.

One of main factor is mounting faulty which is unbalanced matching between tire and rim.